


NOTE:-

- 1] SHUNTS ITEM FITTED TO LINKS
IN POSITIONS SHOWN THUS 
- 2] ALL CONNECTORS [SK, PL, LK, IC SOCKETS] TO BE MOUNTED FLUSH
AND PERPENDICULAR TO THE P.C.B.
- 3] UNLESS OTHERWISE SHOWN, ALL RADIAL LEADED COMPONENTS TO BE
MOUNTED PERPENDICULAR TO THE P.C.B. TO WITHIN +/- 15°
- 4] ENSURE REAR PANEL ITEM IS AT 90° TO THE P.C.B. AFTER ASSEMBLY
- 5] USE WIRE ITEM XX TO HOLD DOWN CRYSTALS
DO NOT SOLDER WIRE TO CAN.